

### **to install:**

1. Cut out and remove the damaged section of pipe.
2. Place clamps over both ends of the pipe.
3. Insert one end of the Poly-Stretch Coupling into the pipe. Extend and insert the other (retracted) end of the Poly-Stretch Coupling into the other side of pipe.
4. Clamp both sides and you have a secure, buckle-free connection.

**material:** ABS plastic

**seal:** BUNA 70 O-ring

**lubricant:** petroleum jelly

**pressure rating:** 160 psi